



GLASSCO

BEAKERS

USER MANUAL



User's Manual for Glassware

BRAND AND MODEL	TYPE	NAME
BRAND: GLASSCO CODE: VARIOUS	CRYSTALLERY	BEAKERS

FUNCTION:

- It is used to store substances, dissolve them, mix them, heat them and in general anything that does not need a precision measurement of volume.
- They have a cylindrical shape and a flat base, with a small mouth at the top to be able to transfer the liquid it contains more easily.

IMAGE:**Technical Description**

- Complies with DIN 12331 and ISO 3819
- Large labeling field for easy marking
- Uniform wall thickness and ideal for heating liquids
- Clear metric graduation for convenience
- Highly resistant to chemical attack
- Material: Borosilicate glass 3.3
- Color: High transparency
- Uniform and bubble-free wall thickness

Available Models

Object code	Capacity (ml)	Diameter (mm)	Height (mm)	Package of	Weight (g)
229.202.01	5	22	30	10	5
229.202.02	10	26	35	10	7
229.202.03	25	34	51	10	19
229.202.04	50	42	58	10	34
229.202.05	100	50	70	10	49
229.202.06	150	60	88	10	91
229.202.07	250	70	95	10	106
229.202.08	400	80	110	10	147
229.202.08A	500	83	118	8	152
229.202.09	600	90	125	8	165
229.202.10	1000	105	157	6	173
229.202.11	2000	132	185	4	192
229.202.13	3000	152	210	1	700
229.202.14	5000	170	270	1	1240
229.202.15	10000	220	350	1	1850

USE**Of the installation**

An asbestos grid is used to heat substances or liquids contained in the glass, since it provides a uniform temperature.

If the glass is hot, it should be taken with gloves or other material.

The preparation of reactions and solutions prepared in the beaker, should never be focused towards our face or body.

Never experiment with very sudden changes in temperature.

Maintenance notes

Requires cleaning of the external and internal surface.

It is recommended to handle the glass with clean hands, do not touch the treated area and clean the entire glass.

Avoid all kinds of abrasive, acid or alkaline based products, especially on laminated glass or camera glasses.

Do not use abrasive brushes, blades or objects that can scratch the glass.

Additional Requirements

N/A

QUANTITY

N/A

GENERAL OBSERVATIONS:

It is recommended to store the equipment in a dry place always keeping the storage precautions for delicate glass material.

PREVENTIVE MAINTENANCE:

- Cleaning the external and internal surface.
- It is recommended to handle the glass with clean hands, do not touch the treated area and clean the entire glass. Avoid all kinds of abrasive, acid-based or alkaline-based products, especially on laminated glass or chamber glass. Do not use abrasive brushes, blades or objects that can scratch the glass.